

Prospective Job Timeline

Acid Stain Interior

- 8am-12pm
 - Prep w/ Satellite pads and clean
- 12pm
 - Apply acid stain
- 4pm
 - Clean acid residue
 - Let dry overnight

-
- 8am
 - Super Prime
 - 12pm
 - WB Urethane

DONE