

Prospective Job Timeline

Pro One Day w/o Primer

- 8-11am
 - Grind
 - Repair
 - Grind (16-30 metals)
- 11-12pm
 - Basecoat and flake
 - Let dry
- 2-3pm
 - Scrape and Vac
 - Put down Poly 90 clear

DONE