



WB Clear Coating System

1. **PREP:** One of the key components is to ensure that the surface is free from sealers, dirt, oils, glues and other contaminants.
 - a. A few methods for properly preparing the concrete are:
 - i. Using a lower grit (80 to 120 grit works on this system) metal bond diamond tool on a 3 headed planetary grinder with a vacuum and grinding dry
 - ii. Use a our Concrete DNA Satellite pad (30 grit)
 1. Also use our Super Blue liquid floor prep and clean water rinse
 - Note: When using water to prep allow the floor to dry a minimum of 24 hours before applying coating.
2. **Apply Super Prime:** Mix Super Prime by drill mixing. Apply the product to the floor by dipping and rolling out of a pan. Use an 18", 3/8" nap roller cover. Coverage rates for dipping and rolling are approximately 300-400 sq ft per gallon depending on the porosity and surface prep method. Don't allow to pool in low areas. Roll out product to an 'even milk' look. Do not over roll. Product hangs out in the bucket/pan. Super Prime is able to be coated over when the surface is tack free and able to be walked on without forming an impression and is within the recoat window.(typically 4-12 hours). If exceeding the maximum recoat window of 12 hours Super Prime must be screened with 220 or coarser screen on a buffer and wiped clean to ensure adequate adhesion of the next coat.
3. **Apply WB Urethane Gloss or Matte:** Mix WB Urethane Gloss/Matte by drill mixing (refer to product data for each products mixing instructions). Apply the product to the floor by dipping and rolling out of a pan. This product can also be poured in ribbons on the floor and spread evenly as you go. Do not allow to sit on the floor very long before rolling. Do not over roll. It is important to get even coverage on the floor to avoid roller marks. This product goes on white and dries clear. This product can also be poured on the floor and spread evenly with a roller. Use an 18", 3/8" nap roller cover. Application rate is around 300 - 400 sq ft per gallon
 - a. Add traction additive if desired. Our Grip X (100 grit) or Wear Pack (220 grit) are good options. Test and area prior to use to ensure this is the grip size you like
 - i. Protect area from traffic until the coating has sufficiently dried (typically 20 hours for light foot traffic)

Please Read: We do not sell the 'finished floor'. You are responsible for creating the finished product. Please contact us with any questions. Mock ups are encouraged before doing your project. The information supplied by Concrete Floor Supply about our products and uses is not a representation or a warranty. It is supplied on the condition that you will make your own tests to determine the suitability of the product for your own particular purpose. Any use or application is the sole responsibility of the user. Listed physical properties are typical and should not be construed as specifications.